


**BIG-8 DUCT INSULATION: R-8.0  
(WITH SPACER STRIPS)**

- QUICK, SAFE, AND EASY TO INSTALL
- CLASS 1 / CLASS A FIRE RATING IN ACCORDANCE WITH ASTM E84-09
- REDUCES HEAT LOSS FROM METAL DUCTS - INCREASED EFFICIENCY!

**INSTALLATION METHOD**

(ICC-ES Evaluation Report ESR-1236)

1. Wrap 2" wide spacer strips around the perimeter of the duct (spacers strips are included with the BIG-8 product).  
Spacer strips to be installed at 2' intervals.
2. Wrap EcoFoil® BIG-8 Insulation around the duct with spacers and pull hand-tight (for an R-8 value). Ensure that the printed Code Certification Strip, is facing out. This information must be visible to inspectors.
3. Tape all seams and joints using EcoFoil® R-8 HVAC Tape, specially formulated to adhere to EcoFoil® BIG-8 Duct Insulation.
  - Item Code 15113 (3" x 150')
  - Use of any tape other than the EcoFoil® items above will void the manufacturer's warranty.
4. When properly installed, the spacers will provide a consistent airspace around the duct.
5. Repeat the above steps for the entire length of the ductwork.



**BIG-8 Spacer Wrap for an R-8 Value With Spacer Strips.  
(Spacer Strips included with the BIG-8 product)**

**SUGGESTED PRODUCTS FOR THIS APPLICATION:**

<b>EcoFoil® Insulation Product</b>	EF2280 (Available in Various Dimensions)
<b>EcoFoil® Tape</b>	EF15113 (HVAC)

- a) Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement of EcoFoil® Reflective Insulation products in specific constructions applications. They are not intended to illustrate proper construction methods (which is ultimately the responsibility of the builder or contractor). The installation instructions are only recommendations relating to the location and placement of EcoFoil® Reflective Insulation products and EcoFoil® makes no claims that these construction systems are universally accurate.
- b) All warranties are void if EcoFoil® Reflective Insulation products are used in exterior applications, or in non-enclosed systems or buildings.
- c) Exercise caution when using EcoFoil® Reflective Insulation products near and around electrical wiring and devices.

