


METAL BUILDING RE-ROOF APPLICATION

- IDEAL RE-ROOF SOLUTION FOR METAL BUILDING APPLICATIONS
- DRAMATICALLY IMPROVES THERMAL VALUE OF METAL ROOFING SYSTEM
- REDUCES HEAT GAIN AND LOSS THROUGHOUT THE YEAR
- LOWERS THE RISK OF INTERIOR CEILING CONDENSATION

INSTALLATION METHOD: (Cold Climate Application)

1. For easier installation, measure your roof dimensions and pre-cut the insulation as needed. Pre-cutting the material is easier, safer, and saves time.
2. Attach desired furring material onto the existing metal roof (slats, hat channels, etc).
3. Starting at the gable, unroll the first row of insulation from the ridge to eave, atop the installed furring material.
4. Make sure the reflective side of the insulation faces the open airspace created by the furring.
5. Install the first metal roofing panel over the insulation, and attach to the furring material as needed.
6. Unroll the next row of insulation directly beside the first. Secure the seams with EcoFoil® Tape.
7. Continue installing insulation and metal panels until the roofing is complete.



SUGGESTED PRODUCTS FOR THIS APPLICATION:

EcoFoil® Insulation Product	EF2210, EF2220 or EF2510, EF2520 Series (Reflective side MUST face the furring airspace)
EcoFoil® Tape	EF15073 (Reflective) or EF15853 (White Poly)

- a) Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement of EcoFoil® Reflective Insulation products in specific constructions applications. They are not intended to illustrate proper construction methods (which is ultimately the responsibility of the builder or contractor). The installation instructions are only recommendations relating to the location and placement of EcoFoil® Reflective Insulation products and EcoFoil® makes no claims that these construction systems are universally accurate.
- b) All warranties are void if EcoFoil® Reflective Insulation products are used in exterior applications, or in non-enclosed systems or buildings.
- c) Exercise caution when using EcoFoil® Reflective Insulation products near and around electrical wiring and devices.

