

**METAL BUILDING WALL (NEW)
(WALL INSTALLATION - DRAPED METHOD)**


- IDEAL INSULATION FOR METAL FRAME BUILDING APPLICATIONS
- QUICK AND EASY TO INSTALL
- REDUCES HEAT LOSS AND HEAT GAIN ALL YEAR ROUND
- WILL BLOCK UP TO 96% OF RADIANT HEAT TRANSFER

INSTALLATION METHOD

1. Begin attaching EcoFoil® Reflective Insulation by first applying double-sided tape on the C or Z channels.
2. Unroll the product.
3. Attach wall panels as usual

Builder's Notes:

- If a white interior finish is desired, EcoFoil® poly reflective insulation may be used. Install as per usual method, however with poly-white side facing interior.
- Use EcoFoil® white poly tape to seal all seams and butt joints.
- When EcoFoil® insulation comes in direct contact with ACQ lumber, it may discolour. This will not affect the overall insulation value of EcoFoil® insulation.



SUGGESTED PRODUCTS FOR THIS APPLICATION:

EcoFoil® Insulation Product	EF2210, EF2510, EF2220, or EF2520 (Available in Various Dimensions)
EcoFoil® Tape	EF15073 (Reflective), EF15853 (White Poly)

- a) Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement of EcoFoil® Reflective Insulation products in specific constructions applications. They are not intended to illustrate proper construction methods (which is ultimately the responsibility of the builder or contractor). The installation instructions are only recommendations relating to the location and placement of EcoFoil® Reflective Insulation products and EcoFoil® makes no claims that these construction systems are universally accurate.
- b) All warranties are void if EcoFoil® Reflective Insulation products are used in exterior applications, or in non-enclosed systems or buildings.
- c) Exercise caution when using EcoFoil® Reflective Insulation products near and around electrical wiring and devices.




**METAL BUILDING WALL (NEW)
(WALL INSTALLATION - FURRING METHOD)**

- IDEAL INSULATION FOR METAL FRAME BUILDING APPLICATIONS
- QUICK AND EASY TO INSTALL
- REDUCES HEAT LOSS AND HEAT GAIN ALL YEAR ROUND
- WILL BLOCK UP TO 96% OF RADIANT HEAT TRANSFER

INSTALLATION METHOD

1. Beginning at end purlin, attach EcoFoil® Reflective Insulation. Double-sided tape can be used if necessary to temporarily hold the product in place.
2. Unroll the reflective insulation, pull tight and continue mounting product to purlins.
3. Apply EcoFoil® tape to seams.
4. Attach 3/4" -1" strapping overtop of the insulation.
5. Attach wall panels as per usual method creating an enclosed air space between product panels and insulation.



Builder's Notes:

- If a white interior finish is desired, EcoFoil® white reflective insulation may be used. Install as per usual method, however with poly-white side facing interior.
- Use EcoFoil® white tape to seal all seams and butt joints.
- When EcoFoil® insulation comes in direct contact with ACQ lumber, it may discolour. This will not affect the overall insulation value of EcoFoil® insulation.

SUGGESTED PRODUCTS FOR THIS APPLICATION:

EcoFoil® Insulation Product	EF2210, EF2510, EF2220, or EF2520 (Available in Various Dimensions)
EcoFoil® Tape	EF15073 (Reflective), EF15853 (White Poly)

- a) Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement of EcoFoil® Reflective Insulation products in specific constructions applications. They are not intended to illustrate proper construction methods (which is ultimately the responsibility of the builder or contractor). The installation instructions are only recommendations relating to the location and placement of EcoFoil® Reflective Insulation products and EcoFoil® makes no claims that these construction systems are universally accurate.
- b) All warranties are void if EcoFoil® Reflective Insulation products are used in exterior applications, or in non-enclosed systems or buildings.
- c) Exercise caution when using EcoFoil® Reflective Insulation products near and around electrical wiring and devices.

