MINI STORAGE APPLICATION

- **- IDEAL FOR MINI STORAGE BUILDINGS WITH FLAT, GABLE, AND SINGLE SLOPE ROOFING**
- **- QUICK AND EASY TO INSTALL**
- **- REDUCES HEAT LOSS AND HEAT GAIN ALL YEAR ROUND**
- **- CAN BLOCK UP TO 96% OF RADIANT HEAT TRANSFER**

INSTALLATION METHOD

1. Measure distance from eave to eave.
2. To ensure EcoFoil® insulation is applied level and in-line, snap a chalk line along the length that the insulation will run.
3. Cut a piece of EcoFoil® insulation slightly longer than the length measured in step 1. This extra length will allow the material to drape between purlins.
4. Unroll EcoFoil® insulation from the ridge, draping material between purlins.
5. Mechanically fasten to eave by using self-tapping screw or staples.
6. Install first metal roofing piece as per manufacturer's instructions.
7. Repeat steps 3-6 for the remainder of the insulation and roofing.
8. Seal all seams and butt joints using EcoFoil® tape to ensure a continuous vapour barrier.

EcoFoil®
Tape

EcoFoil®
Insulation

SUGGESTED PRODUCTS FOR THIS APPLICATION:	
EcoFoil® Insulation Product	EF2210, EF2510, EF2220, or EF2520 (Available in Various Dimensions)
EcoFoil® Tape	EF15073 (Reflective), EF15853 (White Poly)